



# QUICK START GUIDE



## POWER ON

Short press **POWER**: Timebar starts up waiting to be synchronized by app or external timecode

Long press **POWER**: Timebar starts up generating timecode with Time of Day (RTC)

## POWER OFF

Long press **POWER**: Timebar turns off

## BRIGHTNESS

Press **A** & **B** at once: Enter Brightness Selection

▶ Press **A** or **B**: Select Brightness Level (1–31/Auto)

## BRIGHTNESS BOOST

Press **A** & **B** twice: Brightness Boost for 30 Seconds

① All these functions and other settings are also accessible through the Tentacle Setup App

## MODE

Press **POWER**: Enter Mode Selection

▶ Press **A** or **B**: Browse Modes

▶ Press **POWER**: Select Mode

## TIMECODE

**A**: Show User Bits for 5 Seconds

**B**: Hold Timecode for 5 Seconds

## TIMER

**A**: Select one of 3 Timer Presets

**B**: Start/Stop

## STOPWATCH

**A**: Reset Stopwatch

**B**: Start/Stop

## MESSAGE

**A**: Select one of 3 Message Presets

**B**: Start/Stop