




B PANEL240WW

DMX Chart



3 DMX modes

- 1-Channel mode
- 2-Channel mode
- 3-Channel mode



1-channel mode

Channel	Name	Function	Min DMX	Max DMX
1	Dimmer	Dimmer Fine	0	255

2-channel mode

Channel	Name	Function	Min DMX	Max DMX
1	Dimmer	Dimmer Fine	0	255
2	Strobe	Flash to Burst	0	255

3-channel mode

Channel	Name	Function	Min DMX	Max DMX
1	Dimmer	Dimmer Fine	0	255
2	Dimmer	Dimmer Coarse	0	255
3	Strobe	Flash to Burst	0	255